



Italian Section of the Combustion Institute



INTERNATIONAL SYMPOSIUM Emphasizing Energy Transition 21<sup>st</sup> 26<sup>th</sup>JULY, 2024

# Structure and Dynamics of Hexagonal Cells in $H_2/CO_2$ Flames

<u>T. Zirwes</u><sup>1</sup>, S. Eckart<sup>2</sup>, F. Zhang<sup>3</sup>, T.L. Kaiser<sup>4</sup>, K. Oberleithner<sup>4</sup>, O.T. Stein<sup>5</sup>, H. Bockhorn<sup>5</sup>, A. Kronenburg<sup>1</sup>

1) Institute for Combustion Technology (ITV), University of Stuttgart

2) Institute of Thermal Engineering, TU Bergakademie Freiberg

3) Institute for Technical Chemistry, Karlsruhe Institute of Technology

4) Laboratory for Flow Instabilities and Dynamics, Technische Universität Berlin

5) Engler-Bunte Institute, Karlsruhe Institute of Technology

### **Motivation**

### **Motivation**

- Hydrogen is an important fuel for a sustainable energy landscape
- It can be produced from biomass where mixtures of H<sub>2</sub> and CO<sub>2</sub> are created
- Instead of separating CO<sub>2</sub> it can be burned together with H<sub>2</sub>
- However, addition of CO<sub>2</sub> lowers the Lewis number of the mixture, making even rich hydrogen flames thermodiffusively unstable
- In a recent experimental work, cellular structures of H<sub>2</sub>/CO<sub>2</sub> flames were studied on a heat-flux burner
- These types of cellular structures were investigated before in the literature, but no numerical studies are available

### **Experimental setup**

- Heat-flux burner with a burner plate with diameter 30 mm
- Consists of 1519 holes with diameter 0.5 mm
- Plate is actively temperature controlled and can be heated up to 473 K
- OH chemiluminescence
  measurement



### **Numerical setup**

- The numerical setup follows the experiment
- Slightly lower diameter (26 mm)
- 9 mm gas phase considered above the burner plate
- All holes are fully resolved with channels of length 2 mm
- Flame resolved with 15-40 cells
- In-house code EBI-DNS
- Detailed molecular diffusion
- DRM19 reaction mechanism



#### Validation

Comparison of cell structure



Comparison of cell number



### Effect of mass flow rate

### Increasing mass flow rate at constant plate temperature

- Temperature iso-surface T = 900 K colored by OH mass fraction
- Plate temperature 115°C
- Equivalence ratio 0.8
- $H_2/CO_2 = 35/65$
- Transition from band-like to hexagonal structures
- Once the hexahedral cells are formed, their size stay nearly the same but they become more pronounced



A. Kronenburg

### Structure of hexagonal cells

- Typical structure of thermo-diffusively unstable flame
- Flame lifted furthest at negatively curved flame segments
- Likewise, flame burns closest to plate at positively curved flame segments
- (results shown for steady-state simulation)



## **Effect of pre-heating**

### **Effect of pre-heating**



- As the burner plate is cooled at constant mass flow rate, the size of the hexahedral cells increases
- As the burner plate is heated (the gas is preheated), the cells shrink and then transition to the band-like structures
- Eventually, the flame becomes flat
- This can be correlated with the temperature dependent Markstein numbers obtained from 1D counterflow flames



### **Heat losses**

#### Heat losses to the burner plate

- · Heat flux to the burner plate
- For band-like structures, the area with high heat losses is larger
- But for the hexahedral cells, more intense heat loss is observed



#### Heat losses to the burner plate

• The transition from bands to cells can be observed in the total heat loss to the plate:



### Influence of equivalence ratio

- Strong influence of equivalence ratio on cell size
- More detailed analysis left for future work



### Conclusions

- Cellular structures stabilized on flat-flame burners show typical characteristics of thermodiffusively unstable flames
- Increasing mass flow rate enhances local stretch and local heat release rates, but cell diameters stay nearly the same
- Pre-heating decreases the cell size and eventually leads to a flat, thermodiffusivley stable flame
- Full 3D datasets available online (link in paper)



**University of Stuttgart** Institute for Combustion Technology (ITV)

### Thank you!



#### **Thorsten Zirwes**

e-mail thorsten.zirwes@itv.uni-stuttgart.de phone +49 (0) 711 685-65637 www.itv.uni-stuttgart.de/institut/team/Zirwes/

University of Stuttgart Institute for Combustion Technology (ITV) Pfaffenwaldring 31, 70569 Stuttgart, Germany Room 03.313

