




Structuring Ceramics Using Lithography

A direct lithographic way to ceramic microstructures

Michael Schulz

Research Center Karlsruhe, Germany
Albert-Ludwigs-University Freiburg, Germany





Outline

Ceramics in Microsystem Technologies

The lithographic process

Results


Summary




Ceramics in Microsystem Technologies

Challenges


- improved surface roughness
- smallest feature depends on particle size



Centrifugal cast sensor array (PZT)



Injection molded ink jet nozzle (ZrO₂)




Applications

e.g. micro gear components, micro reactors, mold inserts...


Polymer Derived Ceramics (PDC's)

Features


- smooth surfaces
- low sintering temperatures
- no sintering aids needed



Coating




SiC-Fiber $\varnothing = 0,6\mu\text{m}$



micro test structure
topography



The lithographic process




* = optional steps

Lithography application – Possibilities


Microelectronics and Microsystem Technology



Bar structure 400 μm high, with parallel sidewalls.



negative resist



positive resist

MEMS and MOEMS

UV Lithography:

- smallest details 5 μm
- structure height 100 (800) μm
- aspect ratio 5


X-ray Lithography:

- smallest details 0.2 μm
- structure height 1000 (3000) μm
- aspect ratio 50




Lithography resist requirements


- **solid** aggregate state under ambient conditions; in case of UV-lithography an adjustable highly viscous state is acceptable
- **soluble** in standard aprotic organic solvents
- formation of **stable** films on substrate surfaces
- processability at ambient conditions for several hours, i.e. improved chemical **stability against** oxygen and **moisture**
- readily and selectively **soluble** in **developing** solvents
- **availability** and small batch variation
- high sensitivity against **photo chemical induced cross linking** throughout the presence of chromophoric side groups e.g.



Epoxy-



Vinyl-



Acryl-

Suited preceramic polymers so far

	NCP-200	SLM465012VP	Ceraset / VL20	ABSE
	Nichimen Corp.	Wacker	KiON Corp.	IMA Bayreuth Germany
solubility	+	+	+	+
stable films	+	+	-	+
sensitivity against moisture	0	+	+	++
developing	0	+	+	+
radiation sensitivity	UV / X-ray	UV / X-ray	UV / ^{not} tested	- / X-ray
availability	-	-	+	+

- = not suited

0 = suited

+ = well suited

++ = best suited



X-ray dose screening – ABSE

required X-ray bottom dose:


ABSE 500 – 1500 J·cm⁻³ negative resist

compared to:


SU-8 15 J·cm⁻³ negative resist

PMMA 4000 J·cm⁻³ positive resist


solubility of irradiated samples




X-ray induced crosslinking of ABSE





IR-Spectra





Micro test structures from pure ABSE



Pyrolysis
up to 1200 °C




pyrolysis on native substrates




Processing of composites – Influence of deagglomeration on pyrolysed samples

- Significant decrease of open porosity
- Improved density corresponding to the theoretical values
- Hardness up to 1068 ± 36 HV


Raw density of pyrolysed samples



without ultrasound



with ultrasound





Si_3N_4 filler content: 25 vol.%
UBE SN-E10, $d_{50}=0,5 \mu\text{m}$

Micro test structures from powder filled ABSE




before pyrolysis

- high edge precision
- side wall roughness
- low surface roughness
- crack free pyrolysis




40 wt.% Si_3N_4 in the resist material

after pyrolysis



Other composites – standard resist material and ceramic powder



- dispersion of Al_2O_3 -powder in SU-8 standard negative resist
- casting on alumina wafers
- X-ray lithography
- pyrolysis and sintering up to 1550 °C



developed structure
height 360 µm, $\varnothing = 40$ µm



sintered structures



length: 100 µm, width 10 µm
height: 160 µm



Summary

- The lithographic process allows for direct micro structuring of ceramic precursors
- Pyrolysis on native substrates enables crack free and dense micro structured parts
- Low surface roughness and high edge precision possible
- Lithographic structuring of composites possible
- Resolution limited mainly on particle size
- Smallest details of 5 μm were produced
- Resist thickness up to several hundreds of μm were structured



Acknowledgement

Dr. M. Börner	ANKA, Research Center Karlsruhe, Germany
Dr. J. Göttert	CAMD, Baton Rouge, USA
R. Heldele	Research Center Karlsruhe, Germany
Dr. Th. Hanemann	Research Center Karlsruhe, Germany & IMTEK, University of Freiburg, Germany
Dr. P. Meyer	ANKA, Research Center Karlsruhe , Germany
Dr. G. Motz	IMA, University of Bayreuth, Germany
Dr. C. Müller	IMTEK, University of Freiburg, Germany
G. Wiche	IMTEK, University of Freiburg, Germany